



# GRUNT

INSTALLATION INSTRUCTIONS ISUZU DMAX SLOW DOWN EASY UP STRUTS  
PART NUMBER: GUDS-DMAX



**1**

**2**

Fitting to slow down strut

1: On the **DRIVERS SIDE** Remove the bolt nearest to the body

2: Place the bracket as shown and replace the bolt and tighten



**3**

**4**

3: Remove the bolt that holds the strap

4: Replace with the pre assembled strut provided making sure the cable is replaced first

NOTES: ENSURE THE FACTORY WASHER IS REPLACED BETWEEN THE CABLE AND THE BODY  
Duplicate the procedure on the passenger side for the easy lift strut

5: Once the lift strut is installed let the tailgate down and remove the aluminium spacer



**5**

**THESE INSTRUCTIONS ARE A GUIDE WE ALWAYS RECOMMEND BEING INSTALLED BY A PROFESSIONAL & TAKE NO RESPONSIBILITY FOR DAMAGE CAUSED BY INCORRECT FITMENT OF THE PRODUCT TO YOUR VEHICLE**