

VEHICLE Toyota Land Cruiser 76 / 78 / 79 Series
PRODUCT Rear Locker Guard
PART NUMBER SB059

NOTE
Ensure Vehicle is on level ground.
Chock front wheels to avoid vehicle rolling.
TOOLS REQUIRED TO COMPLETE FITMENT
12mm and 14mm socket

1. Remove the (3) original hardware and remove original guard.
See figure 1.
2. Remove white plug from bracket.
3. Fit Blackhawk locker guard.
 - a. Reuse the 2 nuts previously removed.
 - b. Fit supplied M8 bolt.
 - c. Clip wiring plug into upper hole, as highlighted in figure 2.

