


INSTALLATION INSTRUCTIONS

PART DESCRIPTION: 4 Port Diff Breather Kit			
PART LISTING			
ITEM#	PART#	QUANTITY	DESCRIPTION
1		1	4 PORT MANIFOLD BLOCK
2		4	PRESS IN MANIFOLD FITTINGS
3		4	PRESS IN DIFF FITTINGS 1/8 TH NTP
4		4	AIR FILTERS
5		2	STAINLESS STEEL MOUNTING SCREWS
6		2	FLAT WASHERS
7		2	SPRING WASHERS
8		1	LENGTH OF HOSE
9		6	ZIP TIES

NOTE: Read and understand these installation instructions before beginning the installation process. Retain these installation instructions for future reference. It is recommended that this item is to be installed by a qualified person.

NOTES:

- Approximate installation time: 30 Minutes.
- Ensure all parts have been received correctly.
- Ensure parts are suitable for the vehicle prior to undertaking the insulation.



INSTALLATION INSTRUCTIONS

7.

1. Remove factory diff breathers and the outlets off the diffs.
2. Remove the factory gearbox and transfer breathers.
3. Fit the supplied Press in fitting 1/8th NTP into the factory breather ports. Into the factory breather outlets.
4. Find a suitable place to mount the 4-port manifold block as high as possible. Normally in the engine bay against the firewall is the best place to mount the manifold.
5. Mount the manifold block to the desired location using the 2 supplied mounting screws.
6. Run the breathers from the press in fitting to the manifold block making sure to have enough length for full suspension travel, and to keep away from any moving components or high heat like the exhaust.
8. Zip tie the breather lines along the chassis up and out of the way of where they could get damaged.