

# RACKS BRAX.<sup>®</sup>

## COMPATIBILITY POCKET GUIDE

**FOR**



**MAXTRAX**

**FAST ON!  
FAST OFF!**

# AWNING AND ACCESSORY MODELS

CLICK OR TAP ON AN AWNING/ACCESSORY BELOW  
TO TAKE YOU TO THE PAGE TO FIND OUT WHAT YOU NEED

**MAXTRAX® LITE** ..... 3

**MAXTRAX® MINI** ..... 5

**MAXTRAX® MKII** ..... 6

**MAXTRAX® XTREME** ..... 8

**MAXTRAX® JAXBASE** ..... 10



## MAXTRAX® LITE

## ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard <b>AND</b>
ALSO REQUIRED	8210 – HD Accessory Plate Gen 2; Use where brackets <b>cannot be located at 634mm</b> centres, the distance between the centres of the recovery board mounting points. this is typical of roof rack bars or platform racks with slats/bars that run <b>TRANSVERSE</b> (across the width of the vehicle); <b>OR</b>  8173 – HD Accessory Bars Where brackets <b>can be located at 634mm</b> centres (typically for platform racks with slats that run <b>LONGITUDINAL</b> (along the length of the vehicle).

## BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> <li>✓ <b>FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>8300 – HD L50 L Brackets (DOUBLE)*</p> <p>For vertical storage of recovery Boards on the side of vehicle.</p> <p>*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.</p> <p>Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); <b>OR</b></p> <p>8304 – HD Adjustable Brackets Short (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); <b>OR</b></p> <p>8306 – HD Adjustable Brackets Long (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).</p>
<ul style="list-style-type: none"> <li>✓ <b>FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>*ROOF RACKS WITH PERIMETER LIPS REQUIRE <b>PACKERS</b> TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO <a href="#">ROOF RACK GUIDE</a> FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.</p> <p>+ These brackets are both height and angle adjustable.</p>

**WALL MOUNTS** OPTIONAL**BENEFITS**

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

**SECURED LOCATION**

8160 – HD Wall Mounts<sup>+</sup>

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

**UNSECURED LOCATION**

8161 – HD Lockable Wall Mounts<sup>+</sup>

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

<sup>+</sup>NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

# MAXTRAX® MINI

☹️ **SADLY NOT COMPATIBLE** ☹️



## MAXTRAX® MKII

## ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard <b>AND</b>
ALSO REQUIRED	8210 – HD Accessory Plate Gen 2; Use where brackets <b>cannot be located at 890mm</b> centres, the distance between the centres of the recovery board mounting points. this is typical of roof rack bars or platform racks with slats/bars that run <b>TRANSVERSE</b> (across the width of the vehicle); <b>OR</b>  8173 – HD Accessory Bars Where brackets <b>can be located at 890mm</b> centres (typically for platform racks with slats that run <b>LONGITUDINAL</b> (along the length of the vehicle).

## BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> <li>✓ <b>FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>8300 – HD L50 L Brackets (DOUBLE)*</p> <p>For vertical storage of recovery Boards on the side of vehicle.</p> <p>*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.</p> <p>Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); <b>OR</b></p> <p>8304 – HD Adjustable Brackets Short (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); <b>OR</b></p> <p>8306 – HD Adjustable Brackets Long (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).</p>
<ul style="list-style-type: none"> <li>✓ <b>FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>*ROOF RACKS WITH PERIMETER LIPS REQUIRE <b>PACKERS</b> TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO <a href="#">ROOF RACK GUIDE</a> FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.</p> <p>+ These brackets are both height and angle adjustable.</p>

**WALL MOUNTS** OPTIONAL

## BENEFITS

ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

## SECURED LOCATION

8160 – HD Wall Mounts<sup>+</sup>

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

## UNSECURED LOCATION

8161 – HD Lockable Wall Mounts<sup>+</sup>

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

<sup>+</sup>NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.

# MAXTRAX® XTREME

## ITEMS REQUIRED MINIMUM FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
HITCHES NEEDED	8159 – HD Hitch Standard <b>AND</b>
ALSO REQUIRED	8210 – HD Accessory Plate Gen 2; Use where brackets <b>cannot be located at 890mm</b> centres, the distance between the centres of the recovery board mounting points. this is typical of roof rack bars or platform racks with slats/bars that run <b>TRANSVERSE</b> (across the width of the vehicle); <b>OR</b>  8173 – HD Accessory Bars Where brackets <b>can be located at 890mm</b> centres (typically for platform racks with slats that run <b>LONGITUDINAL</b> (along the length of the vehicle).

## BRACKETS REQUIRED FOR FAST ON, FAST OFF!

MOUNTING POINTS	2
BRACKETS NEEDED	
<ul style="list-style-type: none"> <li>✓ <b>FOR BARS OR PLATFORM STYLES WITH TRANSVERSE SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>8300 – HD L50 L Brackets (DOUBLE)*</p> <p>For vertical storage of recovery Boards on the side of vehicle.</p> <p>*These Brackets can also mount to the underside of the Front Runner® Slimline II® platform (sides of the platform only-not rear) and are supplied with extra fasteners for this purpose.</p> <p>Note: Some platform rack styles have limits on load carried on the outer perimeter slat/bars of North to South platforms, e.g. Rhino-Rack® Pioneer® Platform, Pioneer® Tradie and Pioneer Tray® and may require a bracket to bridge across to the inner or 2nd slat as well (see product 8306 below); <b>OR</b></p> <p>8304 – HD Adjustable Brackets Short (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical); <b>OR</b></p>
<ul style="list-style-type: none"> <li>✓ <b>FOR PLATFORM STYLES WITH LONGITUDINAL SLATS (WITH NO PERIMETER LIP)</b></li> </ul>	<p>8306 – HD Adjustable Brackets Long (DOUBLE)**</p> <p>For storing recovery boards to nominally match the rake of the side of the vehicle (15 degrees off vertical).</p> <p>*ROOF RACKS WITH PERIMETER LIPS REQUIRE <b>PACKERS</b> TO FIT RACKSBRAX BRACKETS (SOLD SEPARATELY). REFER TO <a href="#">ROOF RACK GUIDE</a> FOR MORE INFORMATION ON RACKS WITH PERIMETER LIPS.</p> <p>+ These brackets are both height and angle adjustable.</p>



**WALL MOUNTS** OPTIONAL

**BENEFITS**                                 ALLOWS YOU TO REMOVE YOUR ROOF RACK ACCESSORY FROM YOUR VEHICLE SO THAT IT CAN BE FIXED TO A WALL WHEN NOT IN USE.

**SECURED LOCATION**                    8160 – HD Wall Mounts<sup>+</sup>

- ✓ **LOCKED GARAGES**
- ✓ **WORKSHOP WALLS**

**UNSECURED LOCATION**               8161 – HD Lockable Wall Mounts<sup>+</sup>

- ✓ **OPEN CARPORTS**
- ✓ **PUBLIC/SHARED GARAGE AREA**

<sup>+</sup>NOTE: You cannot use Wall Mounts to mount anything to the vehicle – these are for static wall use ONLY.



# MAXTRAX® JAXBASE

☹️ **SADLY NOT COMPATIBLE** ☹️

